



## Color matched and waterproof laminate countertop installation



CF027  
Cool Palette



CF041  
Fog Dust



CF040  
Fog



CF047  
Gray Dust



CF076  
Sarum Gray



CF123  
Natural Aragon



CF036  
Earth Dust



CF268  
Mouse Dust



CF126  
French Walnut



CF290  
Andorra



CF439  
Dark Gray



CF145  
Black Granite



**IPS**  
ADHESIVES

IPS Adhesives  
600 Ellis Road  
Durham, NC 27703 USA

Tel: 919 598 2400

Fax: 919 598 2434

Email: [contact@integra-adhesives.com](mailto:contact@integra-adhesives.com)



# ColorFill

## Key Features:

- Colorfill is a sealant specifically designed for the installation of mitered laminate worktop joints
- It bonds the joint together.
- Seals the joint against water and domestic detergents.
- Is color matched to the countertop making the finished joint almost invisible.
- In addition to countertop joints, ColorFill will repair chips and scratches in laminate and melamine surfaces.
- 12 Colorfill colors have been specifically developed to match the popular brands of laminate across North America.
- ColorFill has been formulated to resist moisture, detergent and other household products as efficiently as the laminate and will withstand heat and direct sunlight.

## Directions for use:

### Countertop Miter Joint

A 25g (0.75 Fl oz) tube of ColorFill is sufficient to seal a 23 1/2" x 1 1/2" or 1" joint.

Apply a thick bead around the leading edge of the joint to both the bottom and top of the exposed core. Quickly close the joint and allow the excess sealant to squeeze out of the joint, align the two sides and tighten the bolts fully. Remove excess sealant with a spatula and clean off the remaining surplus sealant with a solvent moistened tissue taking care not to dislodge any ColorFill still setting in the joint.

### Repairs to Damaged Surfaces

Clean the damaged area with a solvent moistened tissue to ensure there are no oil or grease residues on the surface.

Squeeze a liberal amount of ColorFill onto a spatula and pull back across the damage, filling the area with ColorFill. Leave to dry for 5 minutes.

Clean off the overfill with a solvent moistened tissue around the repair, taking care not to clean out the filled area. Depending on the result a second or third coat may be necessary.

For final clean up allow 24 hours to fully harden and clean the area with household washing up liquid and warm water.